




80-100




80-100



x2




x4



x4


BO-719

01.



Tirar del cajón hacia el frente y ligeramente hacia arriba para extraerlo
 In order to extract the drawer, pull it forward and softly upwards.
 Sortir le tiroir en le soulevant légèrement vers le haut pour l'extraire du meuble.
 Die Schublade nach vorne und leicht nach oben ziehen, um Sie zu entfernen.
 Per tirare fuori il cassetto alzi il fronte e leggermente verso di su.



02.






03.



cms.



04.



x2





x4




x4


BO-719




05.





06.






07.

















08.




09.







BO-719 / A X4




BO-719 / B X4




BO-719 / C X2



128059 X2










138163 X1



138161 X1


01.




BO-719 X2




BO-719 / B X4




BO-719 / A X4




01-1




01-2






01-3




01-4







02.




138163 X1




138161 X1









03.





Ø5





128059 X2





04.





04-1





04-2




04-3




04-4





04-5






NON INCLUS / NOT INCLUDED




x2



x4



x4



x1



x1




x4













BO-850

BO-630



01.



02.



03.






x2


x4

x4




BO-850



04.




X4




x4





04.4



05.





BO-630





06.





06.1





06.2



06.3



06.4



06.5

